PORTABLE MURALS

assembly instructions



1) Insert the top of the mural into an opened plastic sleeve. Start at one end of sleeve and snap the halves together, taking care to keep the mural from falling out. Repeat this step with the second sleeve for the other half of the top of the mural.

2) Now slide the top of the mural (the side with two plastic sleeves) into the larger opening of the aluminum casing. As you do this, be careful that no metal edges scrape the mural. Repeat this step using another aluminum casing on the other half of the top of the mural.



3) Take the two aluminum casings and slide them apart a few inches. Now take the eye-hook with the long base and insert it into the smaller opening of one of the aluminum casings (at the top center of the mural where the two casings will fasten together).

4) Now slide the two aluminum casings toward each other, inserting the eye hook into the other casing as you go. Make sure the eye-hook is centered at the seam.



5) On each outer end of the aluminum casings insert one of the small eye-hooks. They do not need to be inserted too far because they will remain near the ends when hanging.



6) Insert an end cap on each outer end of the aluminum casings.

7) Repeat this whole process for the bottom of the mural. This time you don't need to use any eye-hooks. Instead use the thin plastic bar (which is the same size as the long based eye-hook from Step #3) to join the two aluminum casings securely together.

Sunshine Wallcovering
800-628-7134